

Notebook



Installation Instructions

1. Unscrew the screws on the bottom of your notebook.
2. Find and take out the original hard drive carefully.
3. Unscrew the adapter from hard drive and install it on the SSD.
4. Slide the SSD into the bay.
5. Screw the bottom of your notebook.

BIOS Setting

1. Restart your computer. It should recognize the SSD automatically.
2. Insert the OS set-up CD into your computer.
3. Before entering OS, press ESC, F1 or Delete to run the BIOS.
4. While in the BIOS, set the CDROM Boot Priority. (Please refer to your computer instruction)
5. Save and exit BIOS. (Please refer to your computer instruction)
6. Restart the computer, and install your OS. (Please refer to your computer instruction)
7. Select boot from SSD in BIOS and complete the installation.